ZANUSSI

# DISHWASHER

# ZDI 6743

AUS NZ Instruction book

# Contents


**Important safety information** 3

**Description of the appliance** 4

**The control panel** 4

**Before use** 5
Setting the water softener 5
Filling with salt 6
Rinse aid 6
Use of detergent 7

**Using your appliance** 8
Loading your appliance 8
The lower basket 8
The cutlery basket 8
The upper basket 8
Adjusting the height of the upper basket 9

**Hints and tips** 9

**Washing programmes** 10

**Operating sequence** 11

**Maintenance and cleaning** 12
Internal cleaning 12
Cleaning the filters 12
External cleaning 12
Prolonged periods of non-operation 12
Frost precautions 12
Moving the machine 12

**Something not working** 13
Service and spare parts 14
Protection against flooding 14

**Hints for test centres** 14

**Installation instructions** 15
Water supply connections 15
Water outlet hose connection 15
Electrical connection 15


## Technical specifications

| | | |
|---|---|---|
| Dimensions | Width<br>Height<br>Max depth<br>Max depth with open door | 59.6 cm<br>81.8 - 87.8 cm<br>57.5 cm<br>111.4 cm |
| Electrical connection<br>Motor rating during wash<br>Power of heating element<br>Overall power | Voltage | 220 - 240 V - 50 Hz<br>200 W<br>2100 W<br>2300 W |
| Water supply pressure | Minimum<br>Maximum | 50 kPa (0.5 bar)<br>800 kPa (8 bar) |
| Capacity | | 12 place settings |

CE **This appliance complies with the following E.E.C. Directives:**
**- 73/23 of 19.2.73 (Low Voltage Directive) and subsequent modifications;**
**- 89/336 of 3.5.89 (Electromagnetic Compatibility Directive) and subsequent modifications.**

# Important safety information

**It is most important that this instruction book should be retained with the appliance for future reference. Should the appliance be sold or transferred to another owner, or should you move house and leave the appliance, always ensure that the book is left with the appliance in order that the new owner can get to know the functioning of the appliance and the relevant safety information.**

**This information has been provided in the interest of your safety. You MUST read it carefully before installing or using the appliance.**

## Installation

- This appliance is heavy. Care should be taken when moving it.
- It is dangerous to alter the specifications or attempt to modify this product in any way.
- Care must be taken to ensure that the appliance does not stand on the electrical supply cable.
- Any electrical work required to install this appliance should be carried out by a qualified electrician.
- Any plumbing work required to install this appliance should be carried out by a qualified plumber.
- It is the responsibility of the installer to ensure that the inlet and outlet hoses are not to be bent or obstructed when the machine is installed. If either hose is bent or damaged upon installation it will not be covered by the warranty.

## Child Safety

- This appliance is not intended for use by young children or infirm persons unless they have been adequately supervised by a responsable person to ensure that they can use the appliance safely.
- Young children should be supervised to ensure that they do not play with the appliance.
- Keep all packaging well away from children.
- Keep all detergents in a safe place out of children's reach.

## During Use

- Items that are contaminated by petrol, paint, steel or iron debris, corrosive, acidic or alkaline chemicals must not be washed in this dishwasher.
- Under no circumstances should you open the door whilst the appliance is in operation. Always turn off the appliance before opening the door.
- Only use detergent specifically designed for use in dishwashers.
- When finishing loading or unloading close the door, as an open door can be a hazard.
- Do not sit or stand on the open door.
- Isolate the appliance from the power supply and turn off the water supply after use.
- Care should be taken when cleaning the bottom door seal and hinge area as any exposed metal edges may cut if care is not taken.
- This product should be serviced by an authorised Service engineer, and only genuine spare parts should be used.
- Under no circumstances should you attempt to repair the machine yourself. Repairs carried out by inexperienced or unauthorised persons may cause injury or serious malfunction. Contact your local Service Agent.
  Always insist on genuine spare parts.

## Conservation

**In the interest of the environment:**

- Materials marked with the symbol ♺ are recyclable.
- Check with your local Council or Environmental Health Office to see if there are facilities in your area for re-cycling this appliance.
- When the appliance is to be scrapped, cut off the power supply cable and make the door closing device unusable to prevent young children from being trapped inside.
- Help to keep your country tidy - use authorised disposal sites for your old appliance.

**Warning!**
**Dishwasher detergents are strongly alkaline, they can be extremely dangerous if swallowed.**
**Avoid contact with skin and eyes and keep children away from the dishwasher when the door is open.**
**Check that the detergent receptacle is empty after completion of the wash cycle.**
**Check that the detergent receptacle is empty after completion of the wash cycle.**

# Description of the appliance

1. Levelling spacers
2. Upper basket stop
3. Salt container
4. Lower spray arm
5. Detergent dispenser
6. Control panel
7. Rating plate
8. Rinse aid dispenser
9. Large filter
10. Central filter
11. Upper spray arm
12. Upper basket




# The control panel




## 1. Programme selection push buttons

## 2. Half load push button

This option is useful and economic when only a few dishes need washing.

By pressing this push button, the corresponding indicator light comes on and the prewash phase is automatically excluded.

**If the indicator light is off, the washing programme will be carried out completely.**

Remember to load all the dishes into both baskets.

With the **Quick 50°C** this option is automatically deactivated.

## 3. Delay start push button

This option allows the start of the programme to be delayed by 3, 6 or 9 hours.

## 4. Indicator lights

### Phase indicator lights

**Washing phase**
illuminates when the washing phase is running

**Drying phase**
illuminates when the drying phase is running

**End of programme**
illuminates when the washing programme has ended

### Salt and rinse aid indicator lights

**Salt refilling indicator light**
illuminates when the salt has run out and the salt container requires refilling.

**Rinse aid refilling indicator light**
illuminates when the rinse aid has run out and the rinse aid container requires refilling.

## 5. Door handle

## 6. On/Off indicator light

## 7. On/off push button

# Before use

## Before using your dishwasher for the first time:

1. Ensure that the electrical and water connections comply with the installation instructions
2. Remove all packaging from inside the appliance
3. Set the water softener
4. Pour 1 litre of water inside the salt container and then fill with salt
5. Fill the rinse aid dispenser.

## Setting the water softener

The dishwasher is equipped with a water softener designed to remove minerals and salts from the water supply, which would have a detrimental or adverse effect on the operation of the appliance.

The higher the content of these salts, the harder your water is.

Water hardness is measured in equivalent scales, German degrees, French degrees and PPM (parts per Million).

The softener should be adjusted according to the hardness of the water in your area. Your local Water Authority can advise you on the hardness of the water in your area.

The dishwasher is factory set at level 3.

If this level is not suitable for your area the softener should be adjusted.

| Level | Water hardness | | | Use of salt |
|---|---|---|---|---|
| | **German degrees** (°dH) | **French degrees** (°TH) | **PPM** (Parts per Million) | |
| 1 | < 4 | < 8 | < 80 | NO |
| 2 | 4 - 18 | 8 - 30 | 81 - 300 | YES |
| 3 | 19 - 29 | 31 - 50 | 301 - 500 | YES |
| 4 | 30 - 40 | 51 - 70 | 501 - 700 | YES |
| 5 | 41 - 50 | 71 - 90 | 701 - 900 | YES |

**If your water is level 1 it is already soft and therefore there is no need to use salt.**
**With the setting of the water softener at level 1 the salt indicator light on the control panel will always remain off.**
**Use salt from level 2 upwards.**

**From level 2 upwards, if salt refilling is necessary, the salt indicator light will illuminate only in setting mode and at the end of the washing programme.**
**During the run of the programme it will remain off.**

## To select a different level ensure that the dishwasher is off and then proceed as follows:

1. Press **Normal 65°** and **BIO 50°** programme push buttons simultaneously.

2. While keeping the programme push buttons **Normal 65°** and **BIO 50°** pressed switch on the dishwasher by pressing the On/Off push button.
   The On/Off indicator light comes on.
   At the same time, the indicator lights of the **Normal 65°** and **BIO 50°** push buttons start flashing.




3. Press the **Normal 65°** push button, the indicator light of the **BIO 50°** push button turns off, while the indicator light of the **Normal 65°** push button remains fixed for about 5 seconds and then starts to flash indicating the current level.




   The current level is indicated by the number of flashes made by the **Normal 65°** indicator light, that alternates 5 seconds off with a number of flashes, this continues for about 60 seconds.

   **Example:**
   1 flash = level 1
   2 flashes = level 2
   3 flashes = level 3
   4 flashes = level 4
   5 flashes = level 5

4. To change the level, press the **Normal 65°** programme push button. Each time the push button is pressed the level changes.

   **Example:**
   If the current level is 3, by pressing the **Normal 65°** programme push button once, level 4 is selected.

   If the current level is 5, by pressing the **Normal 65°** programme push button once, level 1 is selected.

   The **Normal 65°** indicator light remains off for about 5 seconds after which it starts flashing indicating the new level selected.

5. To memorise the new level, switch off the dishwasher by pressing the On/Off push button.

## Filling with salt

**Only use salt specifically designed for use in dishwashers.**
**All other types of salt not specifically designed for use in a dishwasher, especially table salt, will damage the water softener.**
**Only fill with salt just before starting one of the complete washing programmes.**
**This will prevent any grains of salt or salty water, which may have been spilled, remaining on the bottom of the machine for any period of time, which may cause corrosion.**

## To fill:

1. To fill with salt, unscrew the cap of the salt container.
2. Pour 1 litre of water inside the container (this is necessary only before filling with salt for the first time).
3. Using the funnel provided, pour in the salt until the container is full.
   Do not worry if water over flows from the unit when filling with salt, this is quite normal.
4. Replace the cap making sure that there is no trace of salt on the screw thread or on the gasket.
5. Screw on the cap tightly.



SR06

The salt container will require topping up periodically.

You are reminded of this by the salt indicator light on the control panel which comes on when the salt has finished.

**The salt indicator light on the control panel can remain illuminated for 2-6 hours after the salt has been replenished, assuming the dishwasher remains switched on. If you are using salts that take longer to dissolve then this can take longer. The function of the machine is not affected.**

## Rinse aid

Rinse aid is automatically added during the last rinse, ensuring thorough rinsing, and spot and streak free drying. The dispenser, which is positioned inside the door, holds about 110 ml of rinse aid, which is sufficient for 16 - 40 dishwashing programmes, depending upon the dosage setting.

## Filling with rinse aid

1. Open the container by turning the lid (A) anticlockwise.
2. Add the rinse aid until the container is completely full.
   The indicator (B) will be completely dark.
3. Top up the rinse aid when the rinse aid indicator light on the control panel illuminates.



BR01



BR03

**If rinse aid refilling is necessary, the rinse aid indicator light will illuminate only in setting mode and at the end of the washing programme.**
**During the run of the programme it will remain off.**

Ensure that the lid is closed after every refill.

Do not put liquid detergent in the rinse aid compartment. Clean up any rinse aid spilt during filling with an absorbent cloth to avoid excess foaming during the next wash.

**It is possible to deactivate the rinse aid indicator light** (see the following instructions). By default the rinse aid indicator light is active.

## To deactivate the rinse aid indicator light ensure that the dishwasher is off and then proceed as follows:

1. Press **Normal 65°** and **BIO 50°** programme push buttons simultaneously.
2. While keeping the programme push buttons **Normal 65°** and **BIO 50°** pressed switch on the dishwasher by pressing the On/Off push button.
   The On/Off indicator light comes on.
   At the same time, the indicator lights of the **Normal 65°** and **BIO 50°** push buttons start flashing.



SO533

3. Press the **BIO 50°** push button, the correspondent indicator light keeps flashing while the indicator light of the **Normal 65°** push button turns off.
   At the same time the indicator light "**end of programme**" starts to flash.



SO535

4. Press the **BIO 50°** push button again, the "**end of programme**" indicator light turns off, this means that the rinse aid indicator light has been deactivated.
5. To memorise the operation, switch off the dishwasher by pressing the On/Off push button.

To reactivate the rinse aid indicator light follow the same process until the "**end of programme**" indicator light starts to flash.

## Adjusting the dose

According to the finish and drying results obtained, adjust the dose of rinse aid by means of the 6 position selector (C) (position 1 minimum dosage, position 6 maximum dosage).

Increase the dose if there are drops of water or lime spots on the dishes after washing.

Reduce it if there are sticky whitish streaks on the dishes.




## Use of detergent

**Only use detergents specifically designed for use in dishwashers.**

### If using powder detergents proceed as follows:

1. Open the dispenser lid by pulling the catch (D).
2. Add the detergent according to the instructions given in the "Washing programmes" chart.
   As all detergents are not the same, you should also consult the instructions on the packet.
3. Always close the lid.
4. The programmes with prewash require a small extra amount of detergent to be poured over the lid of the dispenser. Follow the recommended quantity of detergent given in the "Washing programmes" chart.







### If using detergent in tablets proceed as follows:

1. For all programmes; place 1 tablet inside the detergent dispenser.
2. Always close the lid.
3. For all programmes with prewash; place a portion of a further tablet on the lid of the detergent dispenser.

If detergents in tablets form are used with the **QUICK 50°** programme, it is advisable to put the tablet directly in the dishwasher and **not** in the dispenser or in special tablet containers. This **ONLY** applies to these programmes.

**Attention!**
**Check that the detergent receptacle is empty after completion of the wash cycle.**

**Insufficient quantities of detergent will produce poor washing results, whereas an excessive amount of detergent will not improve washing results and is also wasteful.**
**Using no more than the correct amount also contributes to reducing pollution.**

## Compact detergents with enzymes

In these compact powders the environmentally unfriendly components have been replaced by natural enzymes and other more biodegradable substances.

The enzymes deploy their full dirt dissolving power at a temperature as low as 50°C.

By choosing the BIO/50°C programmes you can therefore achieve the same cleaning results that would otherwise be achievable only with 65°C programmes and conventional detergents.

# Using your appliance

## Loading your appliance

Before placing dishes in the machine, remove any scraps of food, to avoid clogging the filters and consequently reducing the performance.

**Do not load very small items which can fall through the baskets.**

Open the door and slide out the baskets to load the dishes.

## The lower basket

The lower basket is designed to take saucepans, lids, plates, salad bowls, cutlery etc.

Serving dishes and large lids should be arranged around the edge of the basket, ensuring that the upper spray arm can turn freely.


UI48


UI21

The rear rows of prongs on the lower basket can be easily lowered to allow you to load pots, pans and bowls.

**To lower the prongs:**

- Slightly pull them upward and let them drop down (see picture).
- To bring them back to the standing position, just pull them up again.


UI85


UI18

## The cutlery basket

**Long bladed knives stored in an upright position are a potential hazard.**
**These items should only be placed in the removable knife basket.**
**Take care when loading or unloading sharp items such as knives.**

### Removable knife basket

Long and/or sharp items of cutlery such as carving knives must be placed horizontally in the removable knife basket, which is positioned at the rear of the upper basket.


UI53

Cutlery should be placed in the removable cutlery basket with the handles facing downwards. If the handles protrude from the bottom of the basket, obstructing the lower spray arm, load the cutlery with the handles facing upwards.

Mix spoons with other cutlery to prevent them from sticking together.

The cutlery basket is in two parts which can be separated to give greater loading flexibility. To separate the two parts, slide them horizontally in opposite directions and pull them apart. To reassemble, reverse the procedure.


UI07

For best results we recommend you to use the cutlery grids provided (if the size and dimensions of the cutlery allow it).


UI63

## The upper basket

The upper basket is designed for plates (dessert plates, saucers, dinner plates of up to 25 cm in diameter), salad bowls, cups and glasses.

Arrange items on and underneath the cup racks so that water can reach all surfaces.

Glasses with long stems can be placed upside down in the cup racks.

Light items (plastic bowls etc.) must be loaded in the upper basket and arranged so they do not move.


US47

### *In case that plates are loaded in the upper basket:*

*load them starting from the rear positions of the basket; tilting them slightly forwards and avoiding the front positions near the door.*


US71

**Before closing the door, ensure that the spray arms can rotate freely.**

## Adjusting the height of the upper basket

If washing very large plates (over 27 cm and up to 32 cm in diameter) you can load them in the lower basket after moving the upper basket to the higher position.

**Attention!**
**Never lift or lower the basket on one side only.**

**To move to the higher position proceed as follows:**

1. Pull out the basket until it stops.
2. Carefully lift both sides upwards until the mechanism is engaged and the basket is stable.




When the top basket is in the higher position it will only take plates up to 20 cm in diameter and you will not be able to use the cup racks.

**To lower the basket to the original position proceed as follows:**

1. Pull out the basket until it stops.
2. Carefully lift both sides upwards and the allow the mechanism to drop back slowly, keeping hold of it.

**Attention!**
**After loading your machine always close the door, as an open door can be a hazard.**

# Hints and tips

## To save energy

Place dishes in the machine immediately after every meal and wait until the dishwasher is full before washing.

Do not prewash dishes under running water.

Select the washing programme according to the degree of soil and the type of load. Follow the instructions given in the "Washing programmes" chart.

Select the **half load** option if only a few dishes need washing. Remember to load the dishes in both baskets.

## For best washing results

Before loading, remove all scraps of food and soak very heavily soiled pots and pans.

Arrange saucepans, cups and glasses etc. upside-down.

Tilt items with convex or concave surfaces so that the water drains off easily.

Avoid contact between the dishes as far as possible.

## Items not suitable for dishwashers

The following items should not be washed in the dishwasher (unless they are sold as dishwasher proof):

- Cutlery with wooden or horn handles or glued parts
- bronze cutlery
- saucepans with wooden handles
- aluminium ware
- crystal ware
- leaded glass
- plastic items
- antique or fine decorated china

Certain types of decoration can discolour when washed in a dishwasher.

Crystal-ware and plastic objects, if not guaranteed dishwasher proof should be washed by hand.

Certain types of glass can also become opaque after being washed several times in a dishwasher.

A chemical reaction can occur between silver cutlery and stainless steel cutlery. As a precaution, do not wash together.

Iron and cast iron objects can rust and stain other items.

Aluminium tends to go black, copper, pewter and brass tend to stain.

**If in doubt check with manufacturer of the item.**
**When buying new dishes, ensure that they are dishwasher proof.**

# Washing programmes

| Type of load | Degree of soil | Required push buttons | Recommended quantity of detergent | | Cycle description |
|---|---|---|---|---|---|
| | | | wash | prewash | |
| **Normal 65°** | Normal soil. Crockery, cutlery, pots and pans | On/Off + 65° | 25 g | 5 g | Cold prewash<br>Main wash up to 65°C<br>1 cold rinse<br>1 hot rinse<br>Active drying |
| *** BIO 50°** | Normal soil. Crockery and cutlery | On/Off + BIO 50° | 25 g | 5 g | Cold prewash<br>Main wash up to 50°C<br>2 cold rinses<br>1 hot rinse<br>Active drying |
| **** Quick 50°** | Light soil. Crockery and cutlery | On/Off + 50° | 30 g | / | Main wash up to 50°C<br>1 cold rinse<br>1 hot rinse |
| **Delicate 40°** | Light soil. Delicate crockery, delicate china and glassware | On/Off + 40° | 25 g | 5 g | Cold prewash<br>Main wash up to 45°C<br>2 cold rinses<br>1 hot rinse<br>Active drying |

***** Testing programme for EN 50242 (see "Hints for Test Centres). This programme, developed for the use of detergents with enzymes, allows to achieve, with reduced consumption of energy the same cleaning results that would otherwise be obtained only with the 65°C programmes and conventional detergents. To compensate the lower temperature, the duration of the programme has been prolonged.

****** This is a special programme for quick washing a full load of lightly soiled dishes, glasses and crockery (except pots) so that you may re-use them promptly

# Operating sequence

## 1. Check the filters

Ensure they are clean and properly positioned (see "Maintenance and cleaning").

## 2. Press the On/Off push button

The On/Off indicator light will come on.

## 3. Check that there is rinse aid and salt

The corresponding indicator lights will illuminate if refilling is necessary.

## 4. Load the dishes

Remove any scraps of food.

Pull the lower basket out and arrange the saucepans, plates and cutlery in it.

Pull the upper basket out and arrange the plates, saucers, glasses and cups etc. in it.

Slide the baskets back into the machine.

## 5. Ensure that the spray arms can rotate freely

## 6. Measure out detergent

Add the required amount of detergent into the dispenser according to the recommended quantity given in the "Washing programmes" chart.

**If "half load" option is selected remember that the prewash phase is automatically excluded, so do not put detergent on the dispenser lid**

Close the detergent dispenser lid.

## 7. Close the dishwasher door

## 8a. Setting and starting the programme without "delay start"

Press the push button corresponding to the required programme: the indicator light corresponding to the programme illuminates and the phase indicator lights for that programme start flashing.

The start of the programme will occur after about 6 seconds from the last pressure of a push button (programme or "half load" push button), in this time it is possible to change programme simply pressing the push button of another programme.

Once the programme has started the phase indicator lights will turn off except for the phase under way.

**It is possible to interrupt the programme by:**

- opening the door
- pressing the On/Off push button (in this case all the indicator lights turn off)

Close the door again or press the On/Off, the programme will start from the point in which it was interrupted.

## 8b. Setting and starting the programme with "delay start"

The setting of the delay start occurs before selecting the programme.

Press the delay start push button and selected the desired time (3, 6 or 9 hours) until the indicator light corresponding to the chosen hours flashes.

Press the push button corresponding to the required programme: the indicator light corresponding to the programme illuminates and the phase indicator lights for that programme start flashing.

The start of the countdown will occur after about 6 seconds from the last pressure of a push button (programme or "half load" push button).

The countdown will decrease with step of 3 hours and you are informed of this by the indicator lights of the hours.

During the countdown the only indicator lights illuminated are the programme light and the light of the number of hours to the start of the programme.

Once the delayed time has elapsed the programme will start automatically.

It is possible to stop a countdown in progress or before it starts, simply pressing the delay start push button until the indicator lights of the hours are off.

## 9. To cancel a programme in progress

A programme in progress can be cancelled at any time.

Press for about 3 seconds the push button of the running programme until all indicator lights are off.

Only the On/Off indicator light will remain on once the programme has been cancelled.

It is now possible to select a new washing programme.

## 10. At the end of the washing programme

The dishwasher will automatically stop and the phase indicator light end of programme will come on.

The indicator light of the programme just ended will remain on.

The dishwasher has finished the programme only when the end of programme indicator light is illuminated.

If you do not wait for the end of the programme it will not be possible to start a new programme if first you do not cancel the previous.

(For instructions on how to cancel a programme see point 9)

If during the drying phase (**drying indicator light illuminated**) the dishwasher door is opened or the On/Off push button is pressed, the running programme is automatically cancelled.

In this case the machine returns to setting mode and it is possible to select a new washing programme without cancelling the previous.

Switch off the dishwasher by pressing the On/Off push button and open the door.

Wait a few minutes before removing the dishes; in this way they will be cooler.

Empty the lower basket first and then the upper one; this will avoid water dripping from the upper basket onto the dishes in the lower one.

**Important!**
**In general it is not advisable to open the door while the machine is working; if the door is opened however, a safety device ensures that the machine stops.**
**Care must be taken if the door is opened during the hot phase or immediately after a programme has finished, as steam may escape.**

**When the washing programme has finished, it is recommended that the dishwasher is unplugged and the water tap turned off.**

# Maintenance and cleaning

## Internal cleaning

Ensure that the seals around the door, the detergent and rinse aid dispensers are cleaned regularly with a damp cloth.

We recommend every 3 months to run a 65°C wash programme without dishes using detergent.

## Cleaning the central filter

(After each wash)

Scraps of food may accumulate in the drain filter (A) and should be removed by rinsing the filter under running water.

**To remove the drain filter**

- simply pull it out by the handle.

Once cleaned, refit the filter by pushing it back to its original position until it engages.







## Cleaning the large filter

(Every week)

If necessary clean the large filter (B) on both sides under running water, using a brush.

**To remove the large filter**

1. Remove the spray arm by pulling it upwards on one side.
2. Turn the column (C) anticlockwise by 90° and then slide out the filter.
3. Once cleaned refit it following the above instructions in reverse order.
4. Ensure the filter is in its original position, the handle of the drain filter should be pointing towards the front of the appliance.













**The dishwasher must not be used without filters.**

**Incorrect repositioning and fitting of the filters will produce poor washing results.**

**Cleaning the filters is vital to ensure correct operation of the machine.**

## External cleaning

Clean the external surfaces of the machine and control panel with a damp soft cloth. If necessary use only neutral detergents. Never use abrasive products, scouring pads or solvent (acetone, trichloroethylene etc....).

## Prolonged periods of non-operation

If you are not using the machine for any period of time you are advised to:

1. Unplug the appliance and then turn off the water.
2. Fill the rinse aid dispenser.
3. Leave the door ajar to prevent the formation of any unpleasant smells.
4. Leave the inside of the machine clean.

## Frost precautions

Avoid placing the machine in a location where the temperature is below 0°C. If this is unavoidable, empty the machine, close the appliance door, disconnect the water inlet pipe and empty it.

## Moving the machine

If you have to move the machine (moving house etc....):

1. Unplug it.
2. Turn the water tap off.
3. Remove the water inlet and discharge hoses.
4. Pull the machine out together with the hoses.

Avoid over tilting the machine during transportation.

# Something not working

Certain problems are due to lack of simple maintenance or oversights, which can be solved easily without calling out an engineer. The dishwasher is fitted with a number of alarm systems which can help you to quickly determine the cause of any problems such as the dishwasher will not start or stops during operation, all push buttons are inoperative except for the On/Off push button or the indicator light of the programme underway and one or more of the phase indicator lights (washing, drying, end of programme) are flashing.
Press the On/off push button to switch off the dishwasher and carry out the following suggested corrective actions listed below. Once the checks have been carried out switch on the dishwasher and start a washing programme, if the fault code reappears, contact your local Service Force Centre.

| Symptom | Fault code | Solution |
|---|---|---|
| **The machine will not start** | | ● The door has not been properly closed.<br>● The plug is not properly inserted in the power socket.<br>● There is a power failure. |
| **The machine does not fill with water** | **Washing phase indicator light flashing** | ● Ensure the water tap is open.<br>● Ensure the mains water supply has not been cut off.<br>● The inlet hose may be squashed or bent. Reposition the hose.<br>● The inlet hose may be blocked. Switch off the water supply and clean the filter. |
| **The dishwasher will not drain** | **Drying phase indicator light flashes** | ● The drain hose may be squashed or bent. Reposition the hose.<br>● The sink may be blocked. Clear any blockages.<br>● The drain hose extension is not correct. Follow the instructions for connecting to the waste.<br>● There is no vent in the end of the drain hose. |
| **Protection against flooding is active** | **Drying and washing indicator lights are flashing** | ● Close the water tap and contact the Service Force Centre. |
| **General** | **One or more phase indicator lights are flashing** | ● Switch off the dishwasher. Switch it back on and start the programme.<br>If the alarm reappears, call the local Service Force Centre. |
| **The machine is noisy** | | ● Dishes are rattling against each other, refer to “Loading your machine”.<br>● The spray arms are knocking against the dishes. Refer to "Loading your machine". |
| **The door is difficult to close** | | ● The dishwasher is not level, or not properly built-in. |
| **Visible lime deposits or white film on the dishes** | | ● Check that there is salt and that the salt cap is tight.<br>● Check that the right level of the water softener is set. |
| **The dishes are not quite dry** | | ● The rinse aid has run out or too little is being used. |
| **The dishes are not clean (poor wash)** | | ● The baskets are too full.<br>● The dishes have not been arranged properly.<br>● The spray arms do not rotate<br>● The spray arms are clogged.<br>● The filters are clogged.<br>● The filters are not in the correct position.<br>● Not enough detergent has been used or it is unsuitable.<br>● The detergent is old or has gone hard.<br>● The salt container cap is not properly closed.<br>● The washing programme selected is too gentle. |

If after all these checks, the problem persists, contact your local Service Force Centre, quoting the model and serial number.
This information can be found on the rating plate located on the right hand side of the dishwasher door (see picture).



## Service and spare parts

**This product should be serviced by an authorised Service engineer, and only genuine spare parts should be used. Under no circumstances should you attempt to repair the machine yourself.**

**Repairs carried out by inexperienced persons may cause injury or serious malfunctioning. Contact your local Service Force Centre.**

**Always insist on genuine spare parts.**

**Electric Blue Service & Installations P/L**
**324 Frankston Dandenong Rd,**
**Dandenong. VIC 3175**
**Phone: 1300 654 488**

## Protection against flooding

In order to prevent water floods, the machine has been provided with two devices, having the following characteristics:

**1.** In the water inlet hose (see "Water supply connections").
The device comes into operation as a result of any damage to the water inlet hose and stops the water inflow.
To repair the machine call the Service Centre.

**2.** In the bottom of the machine:
The device comes into operation as a result of any water leaks in the machine.
In case of intervention the "**washing**" and "**drying**" phase indicator lights will start **flashing** (see "Something not working").
In this case, turn off the water tap and call the Service Force Centre.

# Hints for test centres

Before starting any test it is necessary to fill completely with salt the salt container and with rinse aid the rinse aid dispenser.

| | |
|---|---|
| Test standard | EN 50242 |
| Reference programme: | BIO 50°C |
| Load: | 12 standard place settings |
| Rinse aid selector: | position 5 |
| Detergent dosage : | 25 g in the dispenser<br>5 g on the dispenser lid |



Arrangement upper basket

Arrangement lower basket



Arrangement cutlery basket



Arrangement knife basket

# Installation instructions

**Any electrical work required to install this appliance should be carried out by a qualified electrician or competent person.**

**Any plumbing work required to install this appliance should be carried out by a qualified plumber or competent person.**

Remove all packaging before positioning the machine.

If possible, position the machine next to a water tap and a drain.

**Attention!**
Carefully follow the instructions on the enclosed template for building in the dishwasher and fitting the furniture panel.

## Water supply connections

This dishwasher may be fed with either hot (max. 50°) or cold water. Nevertheless we advise you a cold water supply.
A hot water supply is not always efficient with very soiled crockery as it shortens the washing programmes a lot.

The water pressure must be within the limits given in the technical specifications.

Your local Water Authority will advise you on the average mains pressure in your area.

The dishwasher features fill and drain hoses which can be turned either to the left or the right to suit the installation. The locknut must be correctly fitted to avoid water leaks.

Avoid bends or kinks in the hose which could prevent or slow down the water supply.

If the machine is connected to new pipes or pipes which have not been used for a long time, you should run the water for a few minutes before connecting the inlet hose. This will prevent deposits of sand or rust clogging the inlet hose filter.

For making the connection itself, the coupling nut fitted to the machine's supply hose is designed to screw onto either a 3/4 inch gas thread spout, or to a purpose made quick-coupling tap such as the Press-block.

**Do not use, for connection, old hoses which have been used in another appliance.**

The water supply hose is fitted with a safety device, which prevents water from entering the machine should the inner hose split, due to wear.

The problem is signalled by a red indicator which appears in the window (**B** - ① ②).

The retaining ring (**A** - ① ②) must be properly fitted so as to avoid water leaks.




**Note:**
Only for water supply hoses fitted with Lock-fast safety device to prevent inadvertent loosening.

To detach the hose press yellow lever (**C** - ②) and turn the retaining ring anticlockwise ②.

## Water outlet hose connection

The end of the drain hose can be connected in the following ways:

1. To the sink outlet spigot, securing it if necessary with a clip.
2. To a stand pipe provided with vent-hole, minimum internal diameter 4 cm.




The waste connection must be at a height of between 30 cm (minimum) and 100 cm (maximum) from the bottom of the dishwasher.
The drain hose can face either to the right or left of the dishwasher
Ensure the hose is not bent or squashed as this could prevent or slow down the discharge of water.
If you use a drain hose extension it must be no longer than 2 metres and its internal diameter must be no smaller than the diameter of the hose provided.




Likewise the internal diameter of the couplings used for connections to the waste outlet must be no smaller than the diameter of the hose provided.
The sink plug must not be in place when the machine is draining as this could cause the water to siphon back into the machine.

**Attention!**
**Our appliances are supplied with a security device to protect against the return of dirty water back into the machine.**
**If the spigot of your sink has a "no return valve" incorporated this can prevent the correct draining of your dishwasher.**
**We advise you therefore to remove it.**

## Electrical connection

Before plugging the appliance into the wall socket, make sure that:

1. The mains voltage corresponds to the voltage given in the "Technical specifications".
2. The meter, fuses, mains power supply and wall socket can all take the maximum load required.
   Make sure that the socket and plug are compatible without having to use any type of adaptor. If necessary, have the domestic wiring system socket replaced.

**Safety standards require the appliance to be earthed.**
**The manufacture accepts no liability for failure to observe the above safety precautions.**

***From the Electrolux Group.*** *The world's No.1 choice.*

*The Electrolux Group is the world's largest producer of powered appliances for kitchen, cleaning and outdoor use. More than 55 million Electrolux Group products (such as refrigerators, cookers, vacuum cleaners, chain saws and lawn mowers) are sold each year to a value of approx. 14 billion USD in more than 150 countries around the world.*